


# Owner's Manual

## Colebrook 3PC Chat Set

Stock# BH17-092-299-28(Blue)

BH17-092-299-31(Red)

BH17-092-299-34(Tan)



**If you encounter any problems with this product:**

- o **DO NOT RETURN IT TO THE STORE**
- o Email: [customerservice@leisuregardenfurniture.com](mailto:customerservice@leisuregardenfurniture.com)
- o Call our customer service hot-line at 1- 877- 877-1235  
8:00am - 4:00pm (PST), Monday- Friday

# Warranty

## **You must retain the original receipt to obtain warranty service.**

All structural frames produced from cast and/or tubular aluminum, steel, and wrought iron.

All furniture manufactured and sold by Pasco Enterprises Ltd. is warranted to the original purchaser against defects in workmanship and materials. If a product manufactured by Pasco Enterprises Ltd. fails during the first year from date of purchase under the terms of our limited warranty, Pasco Enterprises Ltd. will replace the item at no charge. After (1) year it will be the original purchasers' responsibility to pay for freight and packaging. Pasco Enterprises Ltd. reserves the right, in the case of discontinued or out of production models, to replace with an item of similar quality and style (glass breakage is not warranted).

### **Frame (Cast, Extruded Aluminum): (5) Years**

Frames are warranted against defects in materials and workmanship for a period of five years from the date of original purchase. Damage to frames or welds due to commercial use, improper assembly, exposure to water and sub-freezing temperatures, and/or abuse is not covered, please refer to care and maintenance information for proper cleaning instructions.

### **Frame (Steel, Wrought Iron): (3) Years**

Wrought Iron and steel furniture is warranted for (3) years from the original purchase date against defects in manufacturing and/or workmanship. NOTE: Steel and wrought iron are not warranted for rust, corrosion, or rust staining.

### **Fabric: (1) Year if applicable**

Fabric on cushions, slings, and umbrellas is warranted against separation at the seams for a period of (1) year. Fading, mildew, and discoloration due to exposure to elements, chemicals, and spills are not covered, please refer to care and maintenance information for proper cleaning instructions.

### **Powder Coat and/or Paint: (1) Year**

The powder coat and/or paint are warranted against blistering, peeling, or cracking for a period of one year. Fading resulting from exposure to elements, chemicals, and spills is not covered. Scratches and chips due to normal wear and use are not covered, please refer to care & maintenance information for proper cleaning instructions.

### **Resin Wicker Weave and/ or Vinyl Strap: (1) Year**

Weave and/or straps are warranted against breakage, separation, or tearing for one year. Fading or discoloration due to exposure from chemicals, spills, and/or the elements is not covered, please refer to care & maintenance for proper cleaning instructions.

### **Umbrella: (1) Year if applicable**

Umbrella frames are warranted for one year against manufacturer's defects in workmanship and materials. Umbrella bases are not covered, please refer to care & maintenance instructions for proper cleaning information.

### **Freight & Packaging: (1) Year**

Pasco Enterprises Ltd. will be responsible for shipping, handling, and packaging charges for the first year for all valid warranty claims. These charges are the sole responsibility of the claimant after the first year. Shipping is limited to USA only.

## **Warranty Exclusions:**

Products used for commercial, contract, or any other non-residential purposes. Furniture is sold "as is",

display models and/or clearance items.

Warranty exclusions include: freight damage, damage due to acts of nature, fire, abuse, vandalism, lack of proper care and maintenance, fading cushions, slings, umbrellas, and coatings. Glass breakage, table top damage, hardware corrosion & rust, freeze damage, and improper assembly are not covered or warranted. We reserve the right to substitute similar quality and style merchandise/furniture if the model in question is out of stock or production.

NOTE: Rust, corrosion, and/or rust stains are not covered by Warranty.

Glass/ tile/ GRC is replaceable within one year after purchase, excluding glass/ tile/ GRC breakage that is caused by unreasonable or abusive use, fire, freight damage, acts of nature, accidental damage, repair or modifications by customers.

Warranty covers free replacement of item within one year of purchase. If after 1 year of purchase, customer will need to pay freight for replacement item.

**Lack of original receipt will void warranty service.**

## Care & Maintenance

Never allow water to build up in frames as this will cause corrosion and freeze damage in cold climates. Wash all frames with a solution of mild soap and water. Rinse with clean water and dry with a soft absorbent cloth towel. Frames can be treated with a liquid wax for maximum protection against UV rays and/or salty damp air. If your set includes cushions, slings, and/or an umbrella they may be cleaned by hand with a solution of soap & water with a clean water rinse, never machine wash cushions, slings, or umbrella covers as this will result in shrinkage or damage.

After cleaning cushions, tip on end and allow to dry, never use a commercial or home dryer to tumble dry fabric goods.

















Do not use bleach or solvents to clean any product. This will void the warranty.

### **Customer Service:**

- **Email:** [customerservice@leisuregardenfurniture.com](mailto:customerservice@leisuregardenfurniture.com)
- **Phone:** 1-877-877-1235
- **Hours of business:** 8:00am - 4:00pm (PST) Monday – Friday

# Parts List

## 2 Deep Chairs

Ref	Description	Illustration	Qty	Ref	Description	Illustration	Qty
A	Right Arm		1*2	G1	Washer (1/4")		4*2
B	Left Arm		1*2	I5	Nut (5/16")		4*2
C	Seat Panel		1*2	G7	Washer (3.0T)		4*2
D	Back Panel		1*2	C1	Allen Wrench (1/4")		1
E	Base		1*2	D4	Hex Wrench (5/16")		2
F	Stem Bracket		1*2	B1	Bolt (5/16"-18 x 1.181")		4*2
G	Back Cushion		1*2	A3	Bolt (1/4"x0.591"L)		4*2
H	Seat Cushion		1*2	A10	Bolt (1/4"x1.575"L)		4*2
				G2	Washer (1.5T)		4*2

# Assembly Instructions


## CAUTION:

Read all the instructions before assembly. Failure to do so may result in faulty assembly and potential injury!


- Assemble product on a soft, non-abrasive surface such as carpet or cardboard to avoid damaging the item.
- Two people required to assemble heavy item. After final alignment, make sure all bolts are securely tightened with caps pressed in place.
- Remove the parts from the carton and take off all protective material. Identify all parts packed in the carton against the parts list.

**WARNING: Do not tighten bolts until product is completely assembled.**


Step 1 –Take off the protecting jackets on the right and left arm.




Step 2 – Assemble left arm (B) to seat panel (C) by using bolt (A3) and washer (G1).




Step 3 – Insert left arm (B) to back panel (D).



Step 4 – Insert seat panel (C) to back panel (D).



Step 5 – Insert right arm (A) to back panel (D).






Step 6 – Assemble right arm (A) to seat panel (C) by using bolt (A3) and washer (G1).

Hardware Used:

Bolt (A3) 2PCS

Washer(G1) 2PCS




Step 7 – Assemble left arm (B) to back panel (D) by using bolt (A10) and washer (G2).

Hardware Used:


Bolt (A10) 2PCS

Washer(G2) 2PCS







Step 8 – Assemble right arm (A) to back panel (D) by using bolt (A10) and washer (G2).




Step 9 – Assemble stem bracket (F) to seat panel (C) by using bolt (B1), nut (I5) and washer (G7). Tighten all the bolts and nuts.



Step 10 – Turn over the seat frame and insert it to base(E).









Step 11 – Put on seat cushion (H) and back cushion (G).



# Parts List

## 1 Bistro Table

Ref	Description	Illustration	Qty	Ref	Description	Illustration	Qty
A	Table Top Rim		1	A2	Bolt 1/4"-20 x 0.472"L		8
B	Connector		1	G2	Washer 1.5T		8
C	Table Leg		4				
D	Glass Top		1				

# Assembly Instructions


## CAUTION:

Read all the instructions before assembly. Failure to do so may result in faulty assembly and potential injury!

- Assemble product on a soft, non-abrasive surface such as carpet or cardboard to avoid damaging the item.
- Two people required to assemble heavy item. After final alignment, make sure all bolts are securely tightened with caps pressed in place.
- Remove the parts from the carton and take off all protective material. Identify all parts packed in the carton against the parts list.

**WARNING: Do not tighten bolts until product is completely assembled.**


Step 1 – Assemble table leg (C) to connector (B) by using bolt (A2) and washer (G2).



Hardware Used:

Bolt (A2)	4PCS
Washer(G2)	4PCS

Step 2 – Assemble table rim (A) to table leg (C) by using bolt (A2) and washer (G2). Repeat this step for the other table leg (C).



Step 3 – Turn over the table and put on the glass top (D).

